How to Hold and Clean the Ocarina



- Place the neck strap around your neck
- Place your fingers according to the picture above
- Use both pinkies to support the ocarina at the bottom edge
- You can rinse the ocarina with water, but do not submerge the ocarina in water. Wait until the ocarina is dry before playing again.
- **This ocarina is fragile. Please handle it carefully.**

Finger Charts